Aula 08 Forense Computacional





Agenda

- ✓ E-mail dos alunos (Vagner)
- ✓ Baixar evidências
- ✓ Ler documentos;
- ✓ Aplicar os conhecimentos;
- ✓ Responder as questões do caso;





- ✓ O sistema em questão é um caso fictício, que foi criado para aplicar os conhecimentos e ferramentas utilizadas em uma investigação.
- ✓ Sua missão é analisar o conteúdo de um disquete apreendido e responder algumas perguntas. O que torna este desafio único, é que você vai precisar de ler o relatório policial antes de continuar o desafio.
- ✓ Assim como em uma investigação real, você terá algumas informações para utilizar como base e algumas evidências, mas cabe a você com suas habilidades técnicas, descobrir as respostas.





✓ O arquivo image.zip, pode ser baixado do site da disciplina ou ftp do Professor:

http://professor.unisinos.br/pneukamp/arquivos/Forense-2012_1/Aula-8.zip

ftp://pneukamp.dyndns.info/caso1.zip

Neste arquivo constam a imagem a ser periciada e mais algumas informações relevantes sobre o caso!





- ✓ Perguntas que devem ser respondidas:
- 1. Quem é o fornecedor de maconha de Joe Jacob e qual é o endereço do seu fornecedor?
- 2. Quais dados cruciais estão disponível no arquivo coverpage.jpg e por que é esses dados cruciais?
- 3. Quais (se houver) outras escolas além de Smith Hill, Joe Jacobs é visto frequente?
- 4. Para cada evidência, demonstre os procedimentos e ações adotadas pelo suspeito para mascará-los?
- 5. Que processos você (o investigador) usou para examinar o conteúdo de cada evidência?





✓ Conferir o MD5 da Imagem

md5sum image.zip > image.md5

Comparar a saída "image.md5" com a fornecida com a documentação

✓ Descompactar a imagem para iniciar a perícia

```
# unzip image.zip
# Is -Ih
```

✓ Dar uma rápida olhada no conteúdo da imagem

```
# strings -e s image > strings.txt
# file image
```

√ Ver o conteúdo da Imagem

hexdump -C image





✓ Criar uma pasta para guardar os arquivos recuperados

mkdir /home/fdtk/aula8/caso1

✓ Montar a imagem para iniciar os trabalhos

mount -o ro,loop,nodev,noexec image /mnt

✓ Ver o conteúdo da imagem

Is -alh /mnt

drwxr-xr-x 2	root	root	7168	Dec 31 1969 ./
drwxr-xr-x 21	root	root	4096	Oct 12 15:30/
-rwxr-xr-x 1	root	root	15585	Sep 11 08:30 cover\ page.jpgc\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
-rwxr-xr-x 1	root	root	1000	May 24 08:20 schedu~1.exe*





- ✓ Fazer uma cópia dos arquivos para uma pasta "/home/fdtk/Aula8/caso1"
- √ # cp /mnt/* /home/fdtk/Aula8/caso1
- √ Ver o tipo e detalhes dos arquivos
- √ # file /home/fdtk/Aula8/caso1/*
- ✓ Ver o conteúdo dos arquivos
- √ # hexdump -C "caso1/cover page.jpgc " | less
- √ # hexdump -C caso1/schedu~1.exe | less





- ✓ Como o Linux permite descompactar arquivos exe, o que tem dentro dele?
- √ # unzip -v caso1/schedu~1.exe

latter case the central directory and zipfile comment will be found on the last disk(s) of this archive.

✓ Putz! Agora ferrou!!! Esta dizendo que não encontrou a assinatura, que não se trata de um arquivo zipado ou que é um disco de um conjunto formado por mais partes......





```
√ Vamos tentar algo diferente

# mkdir fix
# cp caso1/schedu~1.exe fix
# cd fix
# zip -F schedu~1.exe
zip: reading Scheduled Visits.xls
zip warning: schedu~1.exe would be truncated.
Retry with option -qF to truncate, with -FF to attempt full recovery
# zip -FF schedu~1.exe
zip: reading Scheduled Visits.xls compressed size 2282, actual size 950 for Scheduled
Visits.xls
zip warning: schedu~1.exe has been truncated.
```





✓ E agora, como será que ficou o arquivo?

unzip -v schedu~1.exe

Archive: schedu~1.exe

Length	Method	Size	Ratio	Date	Time	CRC-32	Name
16896	Defl:N	938	94%	05-23-02	11:20	8d6055c7	Scheduled Visits.xls
16896		938	94%				1 file

✓ Tentamos novamente?

\$ unzip schedu~1.exe Archive: schedu~1.exe

[schedu~1.exe] Scheduled Visits.xls password:

Qual senha usaar? Tentei algumas!!!!

password incorrect--reenter:

skipping: Scheduled Visits.xls

incorrect password





✓ Voltei a imagem para procurar algo como senha!!

Archive: schedu~1.exe [schedu~1.exe] Scheduled Visits.xls password: goodtimes

inflating: Scheduled Visits.xls

error: invalid compressed data to inflate


\$ Is -I "Scheduled Visits.xls"


-rwxr-xr-x 1 root root 0 May 23 11:20 Scheduled\ Visits.xls*







✓ Tentando com o autopsy











Creating Case: Joe_Jacob


Case directory (/home/Joe_Jacob/) created
Configuration file (/home/Joe_Jacob/case.aut) created

🦁 Creating Case: Joe Jacob - Mozilla Firefox

We must now create a host for this case.











We must now import an image file for this host




















```
# cp image image.fix
```

losetup /dev/loop0 image.fix

dosfsck -u /jimmyj~1.doc -f -r /dev/loop0

dosfsck 2.8, 28 Feb 2001, FAT32, LFN

Undeleting JIMMYJ~1.DOC

Wrong checksum for long file name "Scheduled Visits.exe". (Short name SCHEDU~1.EXE may have changed without updating the long name)

1: Delete LFN

2: Leave it as it is.

3: Fix checksum (attaches to short name SCHEDU~1.EXE)

?3

/cover page.jpgc

Contains a free cluster (420). Assuming EOF.

/cover page.jpgc

File size is 15585 bytes, cluster chain length is 0 bytes.

Truncating file to 0 bytes.

/Scheduled Visits.exe

File size is 1000 bytes, cluster chain length is > 1024 bytes.

Truncating file to 1000 bytes.

Reclaimed 31 unused clusters (15872 bytes) in 1 chain. Perform changes ? (y/n) y

/dev/loop0: 4 files, 73/2847 clusters





```
# losetup -d /dev/loop0
# mount -o ro,loop image.fix /mnt
# Is -la /mnt
total 48
drwxr-xr-x 2
                                              7168
                                                          Dec 31
                                                                      1969
                       root
                                  root
drwxr-xr-x 21
                                              4096
                                                          Oct 12
                                                                     15:30
                       root
                                  root
                                              1000
                                                          May 24
                                                                     08:20
                                                                                 Scheduled\ Visits.exe\ \ \ \ \ \ \ *
-rwxr-xr-x
                       root
                                  root
                                                          Sep 11
                                                                     08:30
                                                                                 cover\page.jpgc\\\\\\\\*
-rwxr-xr-x
                       root
                                  root
                                              0
                                              15872
                                                          Dec 31
                                                                     1979
                                                                                 fsck0000.rec*
-rwxr-xr-x
                       root
                                  root
                                                                                 jimmyj~1.doc*
                                              20480
                                                          Apr 15
                                                                     2002
-rwxr-xr-x
                       root
                                  root
```

```
# mkdir fix2
```

fix2/Scheduled Visits.exe: Zip archive data, at least v2.0 to extract

fix2/cover page.jpgc :empty fix2/fsck0000.rec: JPEG image data, JFIF standard 1.01, resolution

(DPI), 96 x 96

fix2/jimmyj~1.doc: Microsoft Office document data





[#] cp /mnt/* fix2

[#] umount /mnt

[#] file fix2/*

dd if=image of=Scheduled_Visits.zip bs=512 skip=104 count=5

head -1000c Scheduled_Visits.zip |diff - files/schedu~1.exe

unzip -v Scheduled_Visits.zip

Archive: Scheduled Visits.zip

Length	Method	Size	Ratio	Date	Time	CRC-32	Name
16896	Defl:N	2270	87%	05-23-02	11:20	8d6055c7	Scheduled Visits.xls
16896	2270	87%					1 file

unzip Scheduled_Visits.zip

Archive: Scheduled_Visits.zip [Scheduled_Visits.zip] Scheduled Visits.xls password:

goodtimes

inflating: Scheduled Visits.xls

\$ Is -I "Scheduled Visits.xIs"

-rw-rw-rw- 1 root root 16896 May 23 11:20 Scheduled\ Visits.xls

\$ file "Scheduled Visits.xls"

Scheduled Visits.xls: Microsoft Office document data

\$ mv "Scheduled Visits.xls" Scheduled_Visits.xls



